Tradewinds Amplify™ Display System Instructions

Table of Contents

Packing & Unpacking

Table Leaf

Small Parts Box

Frame Section

Protective Bag

Feet Package

Accessory

Standard Kits

Single Panel

Horizontal = 2
Top Vertical = 2
Bottom Vertical = 2
Cross/Hanging = 1
Feet = 0

10' Wall

Horizontal = 6
Top Vertical = 4
Bottom Vertical = 4
Cross/Hanging = 3
Feet = 2

20' Wall

Horizontal = 12
Top Vertical = 7
Bottom Vertical = 7
Cross/Hanging = 6
Feet = 4

Tradewinds Amplify™ Display System Instructions

## Component Identification

Vertical Pole Top

Vertical Pole Bottom

Horizontal

Cross/Hanging Bar

Amplify Shelf Package Single

Amplify Foot

Corner Bracket w/ Thumb Screws

Amplify Monitor Mount

Corner Post

Amplify Peg Board

Double Sided Monitor Mount Adaptor Brackets

LED Arm Light

Heavy Duty Foot

End Cap

Wire Management Clip

Tradewinds Amplify™ Display System Instructions

Assembly

Base & Foot Assembly

1. Identify foot and horizontal tube.
2. Align through hole in horizontal tube with silver protrusion on top of foot and place horizontal tube onto foot.
3. Engage thumbscrew through hole in horizontal tube into foot and turn right until tight.

Foot
X1

Horizontal
X1

Bottom Frame Vertical Installation

1. Identity bottom vertical poles.
2. Open lever handle on end of horizontal tube by pulling outward.
3. Insert end of horizontal tube perpendicularly into end of bottom vertical pole, and align so both tubes are flush.
4. Secure joint by pushing level handle back inward.

Vertical Pole Bottom
X2

Lever Handle

Tradewinds Amplify™ Display System Instructions

Vertical Pole Top

X2

Top Frame Vertical Installation

1. Locate top vertical poles and stack openside of tube into bottom vertical.

1

Horizontal
X1

Top Horizontal Installation

1. Identity horizontal tubes.
2. Open lever handle on end of horizontal tube by pulling outward.
3. Insert end of horizontal tube perpendicularly into end of top vertical pole, and align so both tubes are flush.
4. Secure joint by pushing lever handle back inward.

2

3

4

Continue Building

1. Repeat previous steps until your wall is complete.

Cross/Hanger Bar Installation

1. Identify cross/hanging bars.
2. Insert one end of cross/hanging bar into side hole of vertical pole.
3. Pivot opposite end of spanner into adjacent vertical pole.

Repeat this step for all cells.

Cross/Hanging Bar

Fabric Panel

Fabric Installation

1. Start at the corners of the assembly. Work the silicone edge of the panel into the extrusion at each corner.
2. Press the FlexLock™ edge of the panel into the extrusion near the middle of each extrusion.
3. Work the panel into the extrusion from the corners inward and the middle outward.
4. To Dismantle, lay frame assembly on floor covered with clean drop cloth provided. To help reduce wrinkling, carefully fold fabric panel and pack into fabric panel storage bag.

Graphic Installation Options

Fabric Panel

Amplify Pole

**Accessory
Slots Exposed**
(Required for adjacent graphics)

Fabric Panel

Amplify Pole

**Accessory
Slots Covered**

Fabric Panel

Amplify Pole

**Wrap Around
Graphic**

* Note: These options must be identified before your graphic is produced for appropriate fabric tension and appearance and may be different on each graphic side.

** Note: If graphic is difficult to install, remove cross/hanger bar(s) , install graphic and replace cross/hanger bar(s).

Tradewinds Amplify™ Display System Instructions

Fabric Instalation Tool

Handle

This side faces toward the fabric banner

This side faces away from the fabric banner

Silicone edge

Amplify Frame

1. Start at all four the corners of the assembly. Work the silicone edge of the banner into the groove in the extrusion for the first 6 inches. (Graphic can be attached while frame is laying on the ground or standing up.)

Front wheel

Silicone edge

Guide wall

2. Place the tool onto the installed portion of the fabric banner so the smooth side of the tool faces away from the banner. Align the tool down the center of the installed silicone edge so it lies between the front wheel and guide wall.

Downward pressure

Push tool forward

3. Apply pressure in towards the frame and push the tool forward. It should fully insert the silicone edge as it goes. If the tool begins to skip along the edge, repeat the section with steady inward pressure.

Direction of movement

Direction of movement

Front view of installing frabric with tool

Tradewinds Amplify™ Display System Instructions

Accessories

Corner Connectors

Monitor Mount

Led Arm Light

Peg Board

Wire mangement clip

End Cap

Shelf

Heavy Duty Foot

Half Foot

Full Foot

Corner Post

Monitor Mount - Introduced on 10/8/2019

1.

2.

Back View

Front View

Rotate brackets over frame and tighten wing nuts.

Monitor Mount - Introduce before 10/8/2019

1.

2.

3.

Back

Front

Wire Mangement Clip

1

2

3

Peg Board

2.

Shelf

1.

2.

Tradewinds Amplify™ Display System Instructions

Accessories

LED Arm Light

Light Mount

Light Mount

Amplify
Pole

1

Corner Post

Opening towards
frame

Top
corner
post

Bottom
corner
post

Opening towards
frame

Heavy Duty Foot

1

2

3

Corner Connector

1.

2.

3.

End Cap

End Panel

Amplify
Pole

Tradewinds Amplify™ Display System Instructions

Accessories

Double Sided Monitor Mount

1. Identify standard monitor mount, adaptor brace, washer/stud assembly and wing nut.
2. Fasten adaptor brace to back of the monitor mount using washer/stud assembly and wing nut. The adaptor brace should be level with the monitor mount.

3. Identify monitor mounting hooks.
4. Fasten monitor mounting hooks to monitor by screw hooks into the holes in the back of the monitor.

5. Install standard monitor mount with adaptor brace onto the back of the frame (see page 7).
6. Rest mounting hooks on installed monitor mount. Ensure hooks are fully seated on. A second monitor may be mounted on the opposite side by repeating steps 3-6.

Amplify™ Display System

Insert Fabric Panel

Bracket Extrusion

Graphic Side

1

B

A

A

B

Lift

Once installed, lift end legs up and set down sharply to connection

2

2

3

3

3

SHORT SIDE PANEL SHOWN

4

4